



**3097340 Prodesign 96'-Current Chevy Pony w/Panels G.E.**

Part #	Description
3097312	Driver Running Board
3097313	Passenger Running Board
3097322	Driver Front Cap
3097323	Passenger Front Cap
3097336	Driver Rear Pony Tail
3097337	Passenger Rear Pony Tail
3097314	Driver Front Door
3097315	Passenger Front Door
3097316	Passenger 60% Front Cargo Door
3097317	Passenger 40% Rear Cargo Door
3097318	Driver Body Panel
3097319	Passenger Body Panel
<b>Part #</b>	<b>Secondary Parts # 16</b>
611117	Bracket Chevy GMT 600Van Set
611181	Step Tread Pro GMT600
<b>Part #</b>	<b>Miscellaneous</b>
611187	Screw Trim 1 7/16" x 16' Black
<b>Part #</b>	<b>Hardware</b>
3000104	Bolt Bag

Rev	Date	Auth.	Description
E	10/15/03	WRB	Add New Bolt Bag #

**3097340**

**96'-Current Chevy Pony w/Panels G.E.**