



3097390 Pro.Chevy '03 GMT 610 Smart Step Pkg

Part #	Description
3097351	Front Bumper '03 610
3097332	Driver Running Board G600
3097333	Pass. Running Board G600
3297321	Rear Bumper w/Quarters '03 610
3097355	Driver Front Door G600
3097356	Pass. Front Door G600
3097357	Pass. Front Cargo Door G600
3097358	Pass. Rear Cargo Door G600
3097361	Driver Body G600
3097362	Passenger Body G600
3097338	Driver Front Cap G600
3097339	Pass. Front Cap G600

Part #	Hardware
3000105	Bolt Bag
Part #	Miscellaneous Parts
886502	Tailpipe Chevy Regular
811189	1 7/16" x 20 Screw Trim
Part #	Secondary Parts # 156
730364	Lights, Projector
875033	Bracket Fog Light GMT 610 Pass
875031	Bracket Fog Light GMT 610 Driver
611118	Bracket Chevy GMT600 sm. Step
611812	Bracket License Plate Univ.
611162	Step Tread GMT 600 Sm. Step
611163	Step Tread R. Bumper GMT600

Rev	Date	Auth.	Description
E	10/16/03	WRB	Add New Bolt Bag #

3097390 Pro.Chevy '03 GMT 610 Smart Step Pkg