



<b>Part #</b>	<b>Secondary Parts # 44</b>
611162	Step Tread GMT 600 smart Step
611118	Bracket Chevy GMT 600 Sm. Step
<b>Part #</b>	<b>Miscellaneous Parts</b>
611187	Screw Trim 1 7/16" x 16' Black
<b>Part #</b>	<b>Hardware</b>
3000105	Ball Bag

Rev	Date	Auth.	Description
D	10/15/03	WRB	Add New Bolt Bag #

3097360 Pro. 96'-Current GMT 600 Smart Step Pony	
Part #	Description
3097332	Driver Running Board
3097333	Pass. Running Board
3097355	Driver Front Door
3097356	Pass. Front Door
3097357	Pass. Front Cargo Door
3097358	Pass. Rear Cargo Door
3097361	Driver Body
3097362	Passenger Body
3097338	Driver Front Cap
3097339	Pass. Front Cap
3097336	Driver Rear Pony Tail
3097337	Pass. Rear Pony Tail

**3097360**

**96'-Current GMT 600 Smart Step Pony**