



Note: Front Bumper Only Fits Factory Bumper W/Two (2), Rubber Fins

Part #	Hardware
3000118	Bolt Bag
Part #	Miscellaneous Parts
611851	Tailpipe Astro
Part #	Secondary Parts # 22
611555	Step Tread Dodge Smart Step
611812	Bracket License Plate Univ.
611550	Lights, 1062a Fog Life
611558	Bracket Dodge Smart Step

3395120 Prodesign 98'-Current Dodge Van S.S. Kit (3 Pc. RR Bump.)	
Part #	Description
3095111	Front Bumper
3095135	Rear Bumper (1 PC.)
3095112	Driver Smart Step Running Board
3095113	Passenger Smart Step Running Board
3095114	Driver Front Door
3095115	Passenger Front Door
3095116	Driver Body
3095117	Passenger Body
3095118	Driver Front Cap
3095119	Passenger Front Cap
3095122	Passenger Front 60% Cargo Door
3095123	Passenger Rear 40% Cargo Door
3095124	Driver Door Screw Molding Applique
3095125	Passenger B Post Cap
3095126	Driver Body Screw Molding Applique
3095127	Passenger Door Screw Molding Applique
3095128	Driver Rear Quarter Screw Molding Applique
3095129	Passenger Rear Quarter Screw Molding Applique
3095131	Pass Front Cargo Door Screw Molding Applique
3095132	Pass Rear Cargo Door Screw Molding Applique
3095133	Passenger B Post Screw Molding Applique
3095134	Passenger Body Screw Molding Applique
3095136	Dodge S.S. Driver Rear Quarter Panel
3095137	Dodge S.S. Passenger Rear Quarter Panel

Rev.	Date	Auth.	Description
D	5/21/04	WRB	Description Change 40/60 Doors

3395120

98'-Current Dodge Van S.S. Kit (3 Pc. RR Bump.)