

## How to Install Condenser Package

1. Position condenser assembly in front of radiator making sure of bracket mounting position. Secure assembly to radiator.
2. Connect wiring as shown in Wiring Diagram below.
3. Install #8 refrigerant hose to top fitting of condenser, routed to compressor discharge port.
4. Install #8 refrigerant hose to the receiver drier, route to expansion valve.

### NOTE:

Always use refrigerant oil to lubricate 'O' ring fittings and ensure a leak-proof seal.

## AtwoodAIR Class 'A' Wiring Diagram

